


Hyva Oil Tanks

Oil tank parts

081 02 116 Air breather filter

Consisting of:

Pos.	Part no.	Description	Qty.
A	081 02 117	Air filter element	1
B	081 02 128	Sleeve	1
C	081 02 119	Cover	1
D	081 02 126	Seal	1
E	081 02 127	Bolt	6
F	081 02 125	Filter house	1



147 80 306 Return filter

Consisting of:

Pos.	Part no.	Description	Qty.
A	148 96 991A	Oil filter element	1
B	148 96 928	Flange pipe	1
C	148 96 920	Body	1
D	148 96 950	Seal kit	1
E	148 96 905	Cover	1
F	148 96 980	Spring	1

